


TRANS^{PRO}↓CAP[®]

HEAT PRESS USER'S GUIDE

MP997




PRO  **WORLD[®]**
HEAT APPLIED GRAPHICS • PRESSES • ACCESSORIES

www.ProWorldInc.com

Pro World Inc.
961 Bethel Ave.
Pennsauken, NJ 08110

Toll Free 800-678-8289
Outside U.S. 856-406-1020
Fax 856-406-1025



Specifications

Model No: TransPro Cap MP997

Voltage: 110V

Timer controller range: Adjustable

Rating power consumption: 350W

Temperature adjustment range: 0-399 Celsius / 0 to 750 F

Working dimension: 8 x 15 cm / 3.14" x 5.9"

Figure size: 750mm x 240mm x 380mm / 29.5" x 9.44" x 14.96"

N.W. : 13 KG / 28.6 Lbs

G.W. : 15 KG / 33 Lbs

OPERATION INSTRUCTIONS

Read Before Operating

1. Be sure to operate with safe ground wire!!!
2. Check the voltage before using it.
3. Turn off the machine when not in use.
4. Grasp the handle firmly when opening.
5. Keep children away from the machine.
6. Do not attempt to press products that are not intended for normal heat transfer use.

Operation Procedures

1. Plug in grounded outlet. Turn the machine on and the power supply indicator will be lit.
2. Adjust the temperature by pressing the set button. Use arrows to choose desired temperature. Press the set button again.
3. Allow 20-30 minutes for machine to heat to set temperature.
4. Adjust the timer by pressing the set button. Use arrows to choose desired time duration. Press the set button again.
5. Place transfer on cap with ink side face down and apply according to the transfer application directions. Push down the handle to start transferring your print and lock handle.
4. The buzzer will beep when the time is complete. Push up on the handle and application is complete

Maintenance & Troubleshooting

1. Pressure: If the pressure is not heavy enough or too heavy, please adjust the pressure adjuster. Turn to the right to tighten the pressure, turn left to lower the pressure.
2. Timer If the buzzer doesn't beep or keeps beeping when the duration runs out, then please check the detector switch.
3. Temperature: The temperature LCD will display the temperature reaches the preset value (i.e.: 385 Fahrenheit). If the heating element doesn't work please check the circuit.


Connecting Your Heat Press To An Electrical Outlet

- Connect the power cord into a properly grounded electrical outlet with a sufficient amperage rating.
- Your Pro World Heat Press requires a full 15 amp grounded circuit for 120 volt operation.
- Extension cord use on the heat transfer machines is not recommended.
- Extension cords ,if used, should be as short as possible and not less than 12 gauge. Heavy duty extension cords are highly recommended in this case.

FAILURE TO FOLLOW THESE INSTRUCTIONS CAN CAUSE:

1. *Erratic controller functions.*
2. *Inaccurate displays and slow heat-up.*
3. *The fuse to pop/break.*
4. *Internal malfunctions prevent the machine to perform properly*

WIRING SCHEMATIC



TRANSPRO WARRANTY

Warranty Coverage

TransPro products offered by Pro World are warranted against defects in material and workmanship. Warranty is void if equipment has been damaged by accident, unreasonable use, neglect, unauthorized and/or improper service, or other causes not arising out of defects in material and workmanship. This warranty does not cover damage caused by normal wear and tear, neglect or lack of proper maintenance.

Warranty Duration

The heating element shall be warranted for the life of the cap press. There is a one (1) year warranty on major components, circuit boards and all other components.

Warranty Performance

During the warranty period, and in the event that a situation cannot be resolved by telephone/email and upon PRE-AUTHORIZATION from Pro World equipment must be shipped, freight prepaid to Pro World for service in the original packaging. After 30 days, all shipping and insurance expenses to and from Pro World of in-warranty equipment is solely the responsibility of the customer. Prior to 30 days the shipping costs will be refunded if Pro World deems the equipment to be defective as stated. Pro World cannot be held responsible for improper handling or any other damage incurred in transit. No charge will be made for labor and components for repair of in-warranty equipment. OUT-OF WARRANTY machines will be charged at the repair rates in effect at the time the machine is received.

Warranty Disclaimers

Pro World shall not be liable for loss of use of TransPro equipment or other incidental or consequential costs, expenses, or damages incurred by the original purchaser or any other user. The above warranty provisions constitute the entire agreement between all parties, and supersede any and all prior written and/or oral representations and understandings.

This "Limited Warranty" applies to all TransPro equipment. However, the procedure for obtaining service may vary outside the continental United States. Contact your Pro World representative for warranty information. The purchaser is responsible for compliance with all local laws, regulations and measure. Agreement shall be governed by and construed in accordance with all applicable laws of said region.



www.ProWorldInc.com

Pro World Inc.
961 Bethel Ave.
Pennsauken, NJ 08110

Toll Free 800-678-8289
Outside U.S. 856-406-1020
Fax 856-406-1025