

## STREETWEAR / NO SHOW SOCKS

30-35 SECONDS  
 MEDIUM  
 400° F / 200° C




## ATHLETIC SOCKS / KIDS SOCKS

30-35 SECONDS  
 MEDIUM  
 400° F / 200° C



## FACE MASKS

30-35 SECONDS  
 HIGH  
 390° F / 198° C



## SPORTS BRAS

50-60 SECONDS  
 HIGH  
 400° F / 200° C



## FLEECE GAITERS / BEANIES

30 - 40 SECONDS  
 MEDIUM  
 400° F / 200° C



## NECK GAITERS / HALF GAITERS

40-60 SECONDS  
 HIGH  
 400° F / 200° C



## HEADBANDS / SLEEVES / SPATS

30-35 SECONDS  
 HIGH  
 400° F / 200° C



## BIKINI UNDERWEAR / THONGS / BOYSHORTS

50-60 SECONDS  
 HIGH  
 400° F / 200° C



## BOXERS / DOG TANKS

50-60 SECONDS  
 HIGH  
 400° F / 200° C



## SHIRTS

30-35 SECONDS PARTIAL  
 60 SECONDS ALL-OVER  
 MEDIUM  
 400° F / 200° C



**PRO TIPS:** TO CREATE FAST AND EASY MOCKUPS AND PRINT FILES, USE THE **SILKY SOCKS APP!**

\* MAKE, MAKE, MAKE, POST! IF YOU POST YOU PLANT SEEDS FOR MORE ATTENTION AND ORDERS.  
 ATTRACT MORE ABUNDANCE AND FACE ALL FEARS!

## BLESS YOUR FEET, BLESS YOUR BODY, AND BLESS YOUR BUSINESS!

Note: Different inks require different times to activate and transfer onto the garment in the Sublimation process. So, you may need to adjust based on your set-up. Some heatpresses vary in time, pressure, and temperature displayed versus actual as well. Use these settings as a starting point, but ultimately adjust and find your sweet spot based on your work station and equipment set-up!